


# DiRaGen 30 USB

Multimode Shortwave Exciter  
130KHz - 30MHz

& SPARK-Modulator  
Software



## TECHNICAL DATA

Tuning Range: 130KHz - 30MHz (continuous)  
 Smallest Tuning Step: 1KHz via SPARK (1Hz eff.)  
 RF Output Connector / Impedance: BNC socket / 50Ohms  
 Output Level: -15dBm eff. +/- 3dB typ. (thermal measurement)  
 Audio / IF Input Level: 0.1Vss @ 1KOhm via 3.5mm stereo phone jack socket  
 DRM Output SNR: MER >45dB/ measured via SoDiRa 072 & DREAM Transmitter)  
 USB connector: USB-B (socket) USB 2.0 (backward-compatible)  
 Unwanted Sideband Suppression ( -112KHz): > 60dB  
 Carrier Suppression (-56KHz): >55dB  
 HarmonicsSuppressions: 0-30MHz >40dB; over 30MHz >60dB  
 Spurious Signals Suppression (0-30MHz): >35dB  
 Frequency Stability (15min. warm-up period): +/- 1ppm typ. (20°C)

Max. Baseband Bandwidth (Audio/IF): 20KHz  
 Power Supply / Connector: 12 - 15V DC max. 250mA / 2.1mm DC power socket (positive inner)  
 Operating Temperature: 0 - 40°C  
 Dimensions / Weight: 125 x 71 x 31mm / 0.20kg

What's included ?

DiRaGen 30 USB

Please note: Plug-Power Supply, application software and connecting cables are not included!

Instruction Manual  
Version V2.0



**NTI**®

Rudolf Ille Nachrichtentechnik • P.O. Box 1703 • D - 79507 Loerrach  
 Tel. +49 7621 / 14756 • Fax +49 7621 / 18840 • www.nti-online.de


The DiRaGen 30 USB unit is completely remote controlled via USB.

Before generating an output signal all the required unique settings have to be set. After this procedure these settings are automatically loaded when starting the program again. All settings can be overwritten individually.

Additionally a brief explanation of each option is given as the mouse passes over it.

It is also possible to store a time-controlled automatic switching configuration, e.g from AM to DRM.

The DiRaGen is recognized automatically by SPARK as external device and will be found under >>> External Devices of the start & configuration screen.




### Output frequency setting:

The output frequency of the DiRaGen 30 USB is directly selected (units KHz) within the configuration menu of SPARK: Transmitter >>> Modulation >>> Output Frequency

In our example screenshot the output frequency was set to 5700KHz = 5.700MHz.

The corresponding intermediate frequency (IF) value is set automatically due to the selected DRM bandwidth.



### Starting transmission:


After the application configuration has been finished, the transmission can be started by pressing the start button:



SPARK transfers the frequency information to the DiRaGen 30 USB.

First the yellow CONNECTED-LED does light up followed by the red ON AIR-LED.

The transmission can be stopped by pressing the corresponding red button symbol.



An integrated watchdog function of SPARK checks continuously the connection to the DiRaGen device.

In case of a detected interruption or distortion (e.g. power loss) the DiRaGen is automatically reinitialized.

### Preliminary testing

Before connecting the PC's sound card signal to the exciter it is recommended to check the SNR quality.

Therefore the following configuration is chosen:

#### A: PC with transmitter software


(e.g. DREAM Transmitter Mode)

Adjustings: Robustness Mode B, MSC Protection Level 0, MSC Interleaver Mode 2s, Bandwidth 9KHz, IF 12KHz

#### B: PC with DRM decoder software

(e.g.. SoDiRa)

The soundcard output of A is connected to the soundcard input of B.



The indicated SNR value of B should be at least >50dB. Values >55dB are excellent.

### Input level adjusting

**In order to achieve the highest possible signal-to-noise ratio (SNR) the conversion must be absolutely linear. Overloading or compression degrades the SNR severely.**

The DiRaGen 30 has an easy-to-read integrated overload control (red LED) at the rear panel.

Adjust the PC volume (audio level) control settings until the LED starts just to flicker.

This is the optimum level to reach the highest possible SNR.

Higher input levels lead to compression effects and degrade the output SNR .

**Conclusion: Less is more !**

**In case of further amplification of the RF output signal additional selective filters must be inserted.**

**Additional amplifiers must be operated within their linear range.**

**This is guaranteed when the RMS output power level (measured thermally) is about 10dB below the declared compression point (P-1dB) for peak envelope power (PEP).**

### Rear panel connections

Power supply Input (from sound card) Peak level indication (red LED)

